# Index


**A**

Automatic Event Timer 31

**B**

Back Panel, Receiver 6
Blacked-Out Program 38
Browse Banner 17
  Changing Channels Using the Browse Banner 43
  Displaying Information on Other Programs 24
  Using the Browse Banner 24
Buttons
  Locking the Receiver Front Panel Control Buttons 43
  Receiver Front Panel Control Buttons 5

**C**

Caller ID 47
Changing Channels 19
  Changing Channels Using the Browse Banner 43
Changing Program Languages 49
Channel Locks 41
Closing the Menus 19
Closing the Program Guide 23
Coaxial Cable Connections 6
Control a Cable TV Box with the Remote 55
Control a Tuner or Amplifier with the Remote 55
Control a TV with the Remote 53
Control a VCR (VideoCassette Recorder) or Second VCR 54
Control a VCR with the Remote 54
Control Buttons, Receiver Front Panel 5
Control, Remote 7
Controlling a Device 50
Controlling Other Devices with the Remote 50
Creating VCR Event Timers 38
Creating a VCR Event Timer 38
Customer Service 81

**D**

Device Code Scan 51
Device Codes
  Check the Device Codes 52
  Scan for Device Codes 51
Displaying Program Information 24
  Using the Browse Banner 24
  Using the Program Banner 24

**E**

Event Timers
  Automatic Event Timer 31
  Before an Event Timer Operates 32
  Control a VCR 38
  Editing an Event Timer 36
  Event Timer Frequencies 32
  Event Timer Types 32
  Locks, Blacked-Out Programs, and Event Timers 38
  Manual Event Timer 31

Maximum Number of Event Timers 35
Power Off and Event Timers 38
Quick Record 35
Reviewing Event Timers 37
Setting Up the Receiver and VCR to Use a VCR Event Timer 38
Events (Programs) 31

**F**

Favorite Lists
Changing the Name of a Favorite List 31
Creating or Modifying a Favorite List 30
Making a Favorite List Active 31
Using Favorite Lists 29
Favorites Lists
Front Panel, Receiver 5

**G**

Guide, Program 15, 22

**H**

Highlighting a Choice in a Menu List 20
Highlighting a Menu Option 20

**I**

Information
Problems and Solutions Tables 81

**L**

Legal Notices 108
Limited Warranty 99
Lists of Choices in the Menus
Multiple Choice Lists 20
Single Choice Lists 20
Locks
Accessing a Locked Item or Opening the Locks Menu 40, 45
Changing the Receiver Password 43, 46
Creating or Changing Channel Locks 41
Creating or Changing Rating (Content) Code Locks 41
Entering the Password 40
Hiding Adult Channels 45
How Resetting the Receiver Affects Locks 49
How to Set Locks - A Two Step Process 39
Locking Pay Per View Programs 44
Locking the Receiver 42
Locking the Receiver Front Panel Control Buttons 43
Opening the Locks Menu 40, 45
Personal Identification Number (PIN) 46
Locks Menu (Parental and System Locks Menu) 16

**M**

Main Menu 14
Manual Event Timer 31
Menus 14
Browse Banner 17, 24
Closing the Menus 19
Displaying Program Information 24
Highlighting a Choice in a Menu List 20
Lists of Choices in the Menus 20
Locks Menu (Parental and System Locks Menu) 16
Main Menu 14

Menu Options 19
Menu Structure 7
Opening the Menus 19
Parental and System Locks Menu (Locks Menu) 16
Program Guide 15, 22
Selecting a Choice in a Menu List 20
Selecting a Menu Option 20
System Setup Menu 16
Theme Categories (Themes) Menu 15
Time-Out Feature 19
Using the Menus 19

**O**

On-Screen Messages 82
Opening the Menus 19
Opening the Program Guide 23
Options, Menu 19

**P**

Parental and System Locks Menu (Locks Menu) 16
Opening the Menu When You Have Locked the Receiver 40
Pay Per View Programs
Locking Pay Per View Programs 44
Personal Identification Number (PIN) 46
Power Light 5
Problems and Solutions Tables 81
Using the Remote Control 85
Program Guide 15
Closing the Program Guide 23
Opening the Program Guide 23
Selecting a Program in the Program Guide 23
Using the Program Guide 22
Programs
Events 31

**Q**

Quick Record 35

**R**

Radio Interference 110
Rain and Snow Fade 3
Rating (Content) Code Locks 41
Receiver Back Panel 6
Receiver Front Panel 5
Control Buttons 5
Locking the Front Panel Control Buttons 43
Power Light 5
Smart Card Access Door 5
Remote Control 7
Device Codes, Check the 52
Device Codes, Scan for 51
Using the Remote Control 85
Remote Control - Using the Control a Cable TV Box 55
Remote Control - Using the Control a Tuner or Amplifier 55
Remote Control Modes 50
REN 109
Resetting the Receiver 49
Residential Customer Agreement 102
Ringer Equivalence Number (REN) 109

**S**

Satellite Signal Quality 3
Rain and Snow Fade 3
Solar Interference 4

Selecting a Choice in a Menu List 20
Selecting a Menu Option 20
Selecting a Program in the Program Guide 23
Service, Customer 81
Setting and Using Security Locks
  Locks, Blacked-Out Programs, and Event Timers 38
Setting Up the Receiver and VCR to Use a VCR Event Time 38
Setting up the Remote to Control Other Devices 50
Signal Quality, Satellite 3
Smart Card Access Door 5
Solar Interference 4
Staying Legal 108
System Setup Menu 16

**T**

Telephone Connection
  Testing the Telephone Connection 57
Testing the System 57
  Starting a Test 57
  Telephone Connection 57
Theme Categories (Themes)
  Using Themes 27
Theme Categories (Themes) Menu 15
Themes (Theme Categories)
  Using Themes 27
Timers, Event
  Locks, Blacked-Out Programs, and Event Timers 38
  Power Off and Event Timers 38
  Setting Up the Receiver and VCR to Use a VCR Event Timer 38
Troubleshooting
  Problems and Solutions Tables 81
  Testing the System 57
Trouble-Shooting Tables
  Buying a Pay Per View Program 89
  Changing Channels 88
  On-Screen Messages 82
  Using Event Timers 90
  Using Favorite Lists 88
  Using Locks 87
  Using the Menus 87
  Using the Program Guide or the Browse Banner 87
  Using the Telephone for Voice/Data/FAX 89
TV - Controlling with the Remote 53

**U**

Using the Remote to Control a TV 53
Using Caller ID 47
Using Favorite Lists 29
Using the Menus 19
  Closing the Menus 19
  Displaying Program Information 24
  Highlighting a Choice in a Menu List 20
  Highlighting a Menu Option 20
  Lists of Choices in the Menus 20
  Menu Options 19
  Opening the Menus 19
Using the Program Guide 22
Using the Remote Control 85

**V**

VCR Event Timers 38

**W**

Warranty 99

**Notes**

**Notes**